

# LQH-series

## Installation and Operation Manual



This manual is an integral part of the unit. Please read the manual carefully before installation, operation or maintenance. Keep this manual for future reference.

Product information is subject to change without notice. All trademarks are recognized as the property of their respective owners.

© Autarco Group B.V.  
All rights reserved.

**Contact**

info@autarco.com  
www.autarco.com

**Address**

Torenallee 20  
5617 BC Eindhoven  
The Netherlands

<b>1</b>	<b>Introduction</b>	<b>6</b>
1.1	Read this first	
1.2	Target Audience	
1.3	Product versions covered by this document	
<b>2</b>	<b>Preparation</b>	<b>8</b>
2.1	Safety instructions	
2.2	Package contents	
2.3	Tools required for installation	
2.4	Internal DC switch	
2.5	Notice of use	
2.6	Notice of disposal	
2.7	Explanations of symbols on inverter	
<b>3</b>	<b>Product information</b>	<b>12</b>
3.1	Overview	
3.2	Product identification	
3.3	Product overview	
3.3.1	Single system	
3.3.2	Parallel system	
3.3.3	System with a generator	
3.3.4	System with an 3rd part on-grid inverter (AC coupled)	
3.3.5	System with an Autarco on-grid inverter (paralleled) / feature coming soon	
3.4	Intelligent LED indicators	
3.5	Password Reset	
<b>4</b>	<b>Mounting</b>	<b>19</b>
4.1	Safety	
4.2	Appropriate Mounting Location	
4.3	Mounting instructions	
4.4	Safety clearance	

4.5	Mounting procedure	
<b>5</b>	<b>Installation</b>	<b>22</b>
5.1	Grounding	
5.2	DC connections	
5.3	Battery connection	
5.4	AC connection	
5.4.1	AC Grid & Backup port connection	
5.5	Smart Meter installation	
5.6	Communication cable assembly	
5.6.1	Communication Port Definition	
5.6.2	BMS Port connection	
5.6.3	Meter Port connection	
5.6.4	DRM Port Connection (Optional)	
5.6.5	RS485 Port Connection (Optional)	
5.6.6	Parallel Terminal Connection (Optional)	
5.7	Parallel System Wiring	
5.8	12-pin communication terminal block	
5.8.1	Heat Pump Control Signal connection	
5.8.2	G-V Terminal connection	
5.8.3	ATS Terminal connection	
5.9	Inverter remote monitoring	
<b>6</b>	<b>Commissioning &amp; Configuration</b>	<b>39</b>
6.1	Preparation & Commissioning	
6.2	Installer App	
6.3	Monitoring Setup	
6.4	Inverter Configuration	
6.5	Operating modes	
6.5.1	Self-use mode	
6.5.2	Grid-trading mode	
6.5.3	Off-grid mode	



6.5.4	Reserve or Backup mode	
6.5.5	Grid Trading Schedule (Time of Use)	
6.5.6	Temperature derating	
<b>7</b>	<b>Maintenance</b>	<b>50</b>
<b>8</b>	<b>Disposal</b>	<b>50</b>
<b>9</b>	<b>Troubleshooting</b>	<b>51</b>
<b>10</b>	<b>Product specifications</b>	<b>54</b>

## 1.1 Read this first

This manual contains important information for use during installation and maintenance of the LQH series Autarco inverters. To reduce the risk of electrical shock, and to ensure the safe installation and operation of Autarco inverters, the following safety symbols appear throughout this document to indicate dangerous conditions and important safety instructions.



**DANGER!** Indicates safety instruction, which if not correctly followed, will result in death, injury, or property damages.



**WARNING!** Indicates safety instruction, which if not correctly followed, can result in death, injury, or property damages.



**RISK OF ELECTRIC SHOCK!** Indicates safety instructions, which if not correctly followed, could result in electric shock.



**ATTENTION!** Indicates safety instruction, or valuable tip, which if not correctly followed, could result in minor or moderate injuries.



**NOTE!** Provides valuable tips for optimal installation and operation.



**HOT SURFACE!** Indicates safety instructions, which if not correctly followed, could result in burns.

## 1.2 Target Audience

This manual is intended for anyone who is using Autarco LQH series inverters. Before any further action, the operators must first read all safety regulations and be aware of the potential danger to operate high-voltage devices. Operators must also have a complete understanding of this device's features and functions.



**ATTENTION!** Qualified personnel mean a person with valid license from the local authority in:

- Installing electrical equipment and PV power systems (up to 1500 V).
- Applying all applicable installation codes and using Personal Protective Equipment.
- Analyzing and reducing the hazards involved in performing electrical work.



**WARNING!** Do not use this product unless it has been successfully installed by qualified personnel in accordance with the instructions in chapter 4 "Installation".

## Product versions covered by this document

The main purpose of this user manual is to provide instructions and detailed procedures for installing, operating, maintaining, and troubleshooting the LQHseries of Autarco inverters which includes the following models:

- S2.LQH12000
- S2.LQH15000
- S2.LQH20000

The item code or SKU will include an additional number at the end.

Please keep this user manual available at all times in case of emergency.

## 2.1 Safety instructions



**DANGER!** Do not touch any internal components whilst the inverter is in operation.



**DANGER!** Do not stand close to the inverter during severe weather conditions such as lightning, etc.



Make sure you completely cover the surface of all PV arrays with opaque (dark) material before wiring them or make sure the DC circuit breaker or equivalent DC isolator is disconnected. This is because photovoltaic (PV) arrays create electrical energy when exposed to light, and could cause a hazardous condition.



**WARNING!** The series inverter must only be operated with PV arrays of protection class II, in accordance with IEC 61730, class A.



**WARNING!** The PV inverter will become hot during operation; please don't touch the heat sink or peripheral surface during or shortly after operation.



**WARNING!** Do not directly connect the AC output of the inverter to any private AC equipment. The PV inverter is designed to feed AC power directly into the public utility power grid.



**WARNING!** AC Backup port of LQH inverters is not allowed to connect to the grid.



**WARNING!** The installation, service, recycling, and disposal of the inverters must be performed by qualified personnel in compliance with national and local standards and regulations. Please contact your dealer to get the information of authorized repair facilities for any maintenance or repairmen.



To reduce the risk of fire, over-current protective devices (OCPD) are required for circuits connected to the inverter. The DC OCPD shall be installed per local requirements. All photovoltaic source and output circuit conductors shall have isolators that comply with the NEC Article 690, Part II



Operator must put on the technicians' gloves during the whole process in case of any electrical hazards.



Please refer to the specification of the battery before configuration.

Any unauthorized actions including modification of product functionality of any form will affect the validation of warranty service; Autarco may deny the obligation of warranty service accordingly.

Please ensure that the following items are included in the packaging with your machine:

1x Inverter



1x Back Plate




4x Fixing Screws(M4\*12)




x4 Expansion bolts(M10\*70)



4x PV Connector



1x CAN cable



3X CT



1x Dust Cover




6x RJ45 connector



1 x Bluetooth Antenna



1 x Eastron Meter + meter cable



1 x User Manual

Manual

## 2.3

## Tools required for installation

Hybrid Solar Inverters

Technical Screwdriver



Torqx T20 Scredriver



Wire Strippers 12AWG to 6AWG



Wire strippers 20AWG to 10AWG



LUG Crimping Tool



1 x Channel Locks



Multimeter (AC/DC amps)



Drill and Impact Driver



Torque Screwdriver



MC4 Crimping Tool



## 2.4

## Internal DC switch

Your Autarco LQH series inverter is equipped with an internal DC switch. This switch can be found on the left side of the inverter.

## 2.5

## Notice of Use

The inverter has been constructed according to the applicable safety and technical guidelines. Use the inverter in installations that meet the following specifications ONLY:

1. Permanent installation is required.
2. The electrical installation must meet all the applicable regulations and standards.
3. The inverter must be installed according to the instructions stated in this manual.
4. The inverter must be installed according to the correct technical specifications.



This product shall not be disposed of with household waste. They should be segregated and brought to an appropriate collection point to enable recycling and avoid potential impacts on the environment and human health. Local rules in waste management shall be respected.

## Explanations of symbols on inverter

	<b>DANGER - HIGH ELECTRIC VOLTAGE</b> This device is directly connected to the public grid. All work to the inverter shall be carried out by qualified personnel only. There might be residual currents in inverter for up to 10 minutes because of large capacitors.
	<b>ATTENTION</b> This device is directly connected to electricity DC generators and the public AC grid.
	<b>DANGER – HOT SURFACES</b> The components inside the inverter will get hot during operation, DO NOT touch aluminium housing during operating.
	<b>ATTENTION</b> In case of any work to the inverter, always refer to this manual for detailed product information.
	<b>ATTENTION</b> This device SHALL NOT be disposed of in residential waste. Please go to Chapter 9 “Recycling and Disposal” for proper treatments.
	<b>CE MARK</b> This equipment conforms to the basic requirements of the EU guideline governing low voltage and electromagnetic compatibility.

## 3.1 Overview

Autarco LQH series hybrid inverters are state of the art, high efficiency, robust and reliable inverters. They are easy to install and carry a standard 5-year product warranty, extendable up to 15 years. Our rigorous quality control and testing facilities guarantee Autarco inverters meet the highest quality standards possible. These inverters are the key to our international track record of delivering extremely reliable solar power solutions.

For full specifications: please see chapter 10, “Product specifications”.

## 3.2 Product identification

You can identify the inverter by the serial number (S/N) sticker on the side of the inverter. Important electrical specifications can also be found on the label which can be found on the right side of the inverter housing. Do not remove the label or the serial number as this will void the product warranty.

## 3.3 Product overview

Autarco LQH series inverter connection schematic overview.



### 3.3.1 Single system

The single system consists of PV module, battery, hybrid inverter, CT and smart meter.

The PV Module converts solar energy into electric energy, which is then converted by the inverter to

- charge the battery
- power loads
- feed into the grid.


User can connect heat pump, existing PV plant, generator and ATS.

The system has four working modes: self-use mode, feed in priority mode, off-grid mode and peak-shaving mode.

#### Note

- In the event of a power outage on the grid, the system will seamlessly transition into off-grid mode, providing power exclusively to essential backup loads.
- When the grid recovers, the system switches back to the on-grid operation.
- Supports heat pump start-stop and power control, only when it has a SG Ready label.


#### 3.1 Connection schematic overview



### 3.3.2 Parallel system

User can add inverters and batteries to increase capacity. The system supports up to 6 inverters in parallel. Each battery connects to the inverter with an independent CAN line and is managed by the inverter connected to it.

3.2 Connection schematic overview of parallel system



- CTs or Smart meter, Control signal of Heat Pump, Control signal of Generator or ATS should be connected to the master inverter.
- CTs delivered with the device can only support a system of up to 60 KW. If a higher power parallel system is required, you need to purchase additional CTs.
- Parallel connection of different models is not supported.(For example 12K and 15K can't be connected in parallel)
- Parallel connection of battery input port is not supported.
- The AC backup port can be connected in parallel, and the single-phase output power is 1/2 of the total rated power.
- The length and specification of the cable connecting the backup load to each inverter needs to be the same to ensure that the current is evenly distributed and prevents one of the inverters from being damaged by excessive current. In parallel-system scenarios, it is advisable to ensure uniform specifications and capacities for batteries on both the master and slave inverters.
- In cases where there is a disparity, it is recommended to connect the battery with a larger capacity to the master inverter. Connecting a higher-capacity battery to a slave inverter may result in incomplete discharge during high- load scenarios.


Scenarios	S2.LQH12000 AC capacity (kW)	S2.LQH15000 AC capacity(kW)	S2.LQH20000 AC capacity(kW)	Backup single-phase output power(kW)	Recommended Battery Capacity (For example, AC capacity 12K&Backup 2h)
Single	12	15	20	6	24kWh
2 in parallel	24	30	40	12	24kWh*2
3 in parallel	36	45	60	18	24kWh*3
4 in parallel	48	60	80	24	24kWh*4
5 in parallel	60	75	100	30	24kWh*5
6 in parallel	72	90	120	36	24kWh*6

### 3.3.3 System with a generator


The access of Diesel Generator is in the off-grid scenario. When the battery power is below a set value and a power outage occurs in the grid, the system will start the generator to power the load and charge the battery. Generator's work logic is as follows:

1. when the grid is not available and the battery is discharged to GEN\_Start\_SOC, the generator starts to power the load and charges the battery to GEN\_Exit\_SOC, then the generator stops.
2. If the load power is higher than the generator rated power, the battery will be discharged to power the load until Overdischarge\_SOC, then generator may shutdown due to overload and the load will be powered off.
3. If the generator fail to start in point 1, the battery will be discharged until it reaches Overdischarge\_SOC
4. If the system goes into the end of point 3, the battery will not discharge before it is charged to Overdischarge\_SOC+ Overdischarge\_Hysteresis\_SOC (set by user).

#### 3.3 Connection schematic overview of system with a generator connected to the generator port



### 3.4 Connection schematic overview of system with a generator connected to ATS




When the generator is connected, it is essential to correctly select the generator position on the APP, otherwise it may cause system failure or damage to the generator.

- In single system, a diesel generator can be connected via both AC-Gen port and ATS. In case of AC-Gen port connection, it will only supply power to the backup load; if it is necessary to supply power to the grid side, connection through an ATS is recommended.
- In parallel-system scenarios, connecting a diesel generator via an ATS is recommended.
- When the system is connected to the generator, it cannot be connected to an on-grid inverter, because of a risk of damaging the generator.
- If the generator is connected through an ATS on the grid side (Figure 3.4), then smart meter is required.

### 3.3.4 System with an 3rd party on-grid inverter (AC coupled)

Generally, the access of on-grid inverter is for the retrofit of a existing PV plant. The LQH inverter supports access of both Autarco on-grid inverter and third-party on-grid inverters.


### 3.5 Connection schematics of a system with another on-grid inverter



- Third-party on-grid inverter can be connected via AC-Gen port and AC-Backup port.
- With third-party on-grid inverter connected to the system, it is recommended that: The on-grid inverter has lower AC power compared to the rated AC power of the LQH inverter.
- In an on-grid scenario, when the third-party on-grid inverter is connected, the system cannot control the output power of the third-party on-grid inverter, so Feed-in limitation cannot be realized.
- In off-grid scenario, the third-party on-grid inverter must be configured with the correct grid code and equipped with over-frequency load shedding and under-frequency load rising functionalities. These features allow the system to dynamically adjust the frequency, effectively controlling the output power of the grid-tied inverter.

### 3.3.5 System with an Autarco on-grid inverter (paralleled) // feature coming soon

Generally, the access of on-grid inverter is for the retrofit of a existing PV plant. The LQH inverter supports access of both Autarco on-grid inverter and third-party on-grid inverters.



#### Note

An Autarco on-grid inverter can be connected with the hybrid inverter in parallel. To achieve feed-in limitation, it is necessary to add PELD.

There are five indicators on the Autarco LQH Series Hybrid Inverter (Battery, Power, WiFi, RS485 and Bluetooth) which indicate the working status of the inverter. The Bluetooth Antenna or WiFi datalogger shall be installed on the Antenna/COM port of the hybrid inverter before local debugging.

### 3.4 LQH LED Indicators



### 3.5 LQH LED Status

Light	Status	Description
	Blue flashing every 3s	Battery discharging.
	Blue flashing every 1.5s	Battery charging.
	Blue solid ON	Idle.
Battery	OFF	No battery or not working.
	Blue solid ON	Normally operating.
	Yellow solid ON	Warning.
	RedSolid ON or flashing every 3s	Alarm.
Power	OFF	No battery or not working.
	Blue solid ON	COM port is being used.
	OFF	COM port is not used.
	Blue solid ON	RS485 port is being used.
	OFF	RS485 port is not used.
	Blue solid ON	Bluetooth port is being used.
	OFF	Bluetooth port is not used.



#### ATTENTION! Turning On the LED Indicator Lights

After a few minutes, the LED indicator lights will turn off to conserve power. To turn the lights back on, you can short press the Inverter LED light.



#### WARNING! Alarm State

When the inverter has an alarm, the Inverter LED light turns red and starts flashing. It is recommended to connect to the inverter with the Bluetooth tool. Then you can determine what the alarm code is.



**NOTE!** Battery/WiFi/Ethernet/Bluetooth indicators will automatically turn off after 1 minute. The Power indicator will remain on with lower brightness. Short press the Power indicator can wake up all indicators.

## Password Reset

- If the owner or installer wishes to reset the inverter password, please long press the Inverter indicator for 5s.
- If the reset command is successfully triggered, the status indicator will turn blue and blink for 3s at the frequency of 0.5s, then restore to the original state of the indicator.
- If the command fails to be triggered, the status indicator will be yellow and blink for 3s at the frequency of 0.5s, then restore the original state of the indicator.
- If the command is successfully triggered, the Bluetooth password can be reset in the APP.

## 4.1

## Safety



**DANGER!** Do not install the inverter near flammable or explosive items.



**WARNING!** The installation must be performed by qualified personnel and in compliance with national and local standards and regulations.

This inverter will be connected to a high voltage DC power generator and AC grid. Inappropriate installation may also jeopardize the life span of the inverter.



**ATTENTION!** The installation site must have good ventilation conditions. Direct exposure to intense sunshine is not recommended. Energy production may be lower than expected.



**NOTE!** Nothing should be placed on or against the inverter.

## 4.2

## Appropriate Mounting Location



**ATTENTION!** The heat sink can reach a temperature of 75°C under operation.


- Make sure the mounting wall is strong enough to hold the weight of the inverter.
- The ambient temperature of the installation site should be between -20 °C and +60 °C.
- Make sure of ample ventilation at installation site, insufficient ventilation may reduce the performance of the electronic components inside the inverter and shorten the lifespan of the inverter.
- The inverter has fans that will intelligently cool the inverter if the internal components exceed 100°C. The fan noise should not exceed 60dB.




**ATTENTION!** Two people are required to remove the inverter from the carton and install the inverter.

- The inverter is suitable for outdoor and indoor installation.
- Adequate ventilation must be provided.
- Nothing shall be stored on or placed against the inverter.

#### 4.1 Recommended Installation locations



#### 4.2 Vertical installation is recommended, with a maximum inclination of 15° backwards





## 4.4

## Safety clearance

Hybrid Solar Inverters




**CAUTION!** Make sure heat sinks are out of reach of children.



**WARNING!** When installing multiple inverters, make sure there is sufficient clearance between them. High temperatures may affect performance. Make sure inverter controls are reachable in case of emergency.

Observe the following minimum clearances to walls and other inverters. Front clearance shall be 1000 mm.

### 4.4 Inverter mounting clearance



## 4.5


## Mounting procedure

**Step 1** Mount the wall bracket onto the mounting wall with appropriate screws plugs.


**Step 2** Lower the inverter onto the bracket.

**Step 3** Use screws in the package to fix the bottom of the inverter to the mounting bracket.

### 4.5 Inverter wall mounting



### 4.6 Wall Mount Bracket





**DANGER!** This inverter will be connected to a high voltage DC power generator and AC grid. The installation must be performed by qualified personnel and in compliance with national and local standards and regulations

## 5.1

## Grounding



**DANGER!** Never connect or disconnect the connectors under load.



**NOTICE!** The AC connection to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.



**NOTICE!** Make sure to set the correct grid standard as part of system commissioning, *see chapter 6.3*.

**Step 1** Prepare the grounding cable: recommended to use the 16-35mm<sup>2</sup> outdoor copper-core cable.


**Step 2** Prepare OT terminals, M4.



**WARNING!** No matter what kind of grounding connection is adopted, it is strictly forbidden to connect the ground of the inverter with the lightning protection of a building, otherwise Autarco will not be responsible for any damage caused by lightning.

**Step 3** Strip the grounding cable insulation to the suitable length as shown in *Figure 5.1*.


### 5.1 Suitable length



**NOTE!** (insulation stripping length) is 2-3mm longer than A (OT cable terminal crimping area)

**Step 4** Insert the stripped wire into the OT terminal crimping area and use a hydraulic clamp-tool to crimp the terminal to the wire (as shown in *Figure 5.2*).

### 5.2 Strip wire






**IMPORTANT!** After crimping the terminal to the wire, inspect the connection to ensure the terminal is solidly crimped to the wire.

**Step 5** Remove the screw from the heat sink ground point.

**Step 6** Use the screw of the ground point to attach the grounding cable (as shown as in Figure 5.3). Tighten the screw securely. Torque is 2 Nm.

### 5.3 Connect external grounding conductor



**IMPORTANT!** To improve the corrosion resistance of the grounding terminal, we recommend that the external grounding terminal is coated with silica gel or paint for protection after installation of the grounding cable.

## 5.2 DC connections

Always use the MC4 connectors from the inverter box to connect strings to the inverter.



**DANGER!** Never connect or disconnect the connectors under load.

Please ensure the following before connecting the inverter:



**DANGER!** Do not connect the strings with an open circuit voltage greater than the Max DC voltage of the inverter.



**DANGER!** For protection against electric shock, MC4 connectors must be isolated from the PV array while being assembled or disassembled.



DC connections must not be unplugged while under load. They can be placed in a no-load state by switching off the DC/AC converter or breaking the DC circuit interrupter. Plugging while under voltage is permitted.



**CAUTION!** MC4 connectors are watertight IP67 but cannot be used permanently under water. Do not leave MC4 connectors directly on the roof surface, but always tie them up.



**CAUTION!** If DC inputs are accidentally reversed or inverter is faulty or not working properly, it is NOT allowed to turn off the DC switch. Otherwise, it may cause DC arc and damage the inverter or even lead to a fire disaster. The correct actions are:

- Use a clip-on ammeter to measure the DC string current.
- If it is above 0.5A, please wait for the solar irradiance reduces until the current decreases to below 0.5A.
- Only after the current is below 0.5A, you are allowed to turn off the DC switches and disconnect the PV strings.
- To eliminate the possibility of failure, please disconnect the PV strings after turning off the DC switch to avoid secondary failures due to continuous PV energy on the next day.

Please note that any damages due to wrong installation are not covered in the device warranty.




**ATTENTION!** If any tools or parts are used in the MC4 connector assembly other than those listed in the MC4 connector manual, neither safety nor compliance with the technical data can be guaranteed.

Please ensure the following before connecting the inverter:

- Make sure the voltage of the PV string will not exceed the max DC input voltage (1000 Vdc). Violating this condition will void the warranty.
- Make sure the polarity of the PV connectors is correct.
- Make sure the DC-switch, Battery, AC-BACKUP, and AC-Grid are all in their off-states.
- Make sure the PV resistance to ground is higher than 20K ohms.

Please follow the picture below to assemble the MC4 connectors. To connect the PV generator to the inverters we use 4mm<sup>2</sup> or 6mm<sup>2</sup> PV cable and MC4 connectors. For details on how to assemble MC4 connector please refer to our MC4 connector manual.

#### 5.4 DC Solar Cable connection





**DANGER!** Do not connect the strings with an open circuit voltage greater than the Max DC voltage of the inverter.



**DANGER!** For protection against electric shock, MC4 connectors must be isolated from the PV array while being assembled or disassembled.



DC connections must not be unplugged while under load. They can be placed in a no-load state by switching off the DC/AC converter or breaking the DC circuit interrupter. Plugging while under voltage is permitted.



**CAUTION!** MC4 connectors are watertight IP67 but cannot be used permanently under water. Do not leave MC4 connectors directly on the roof surface, but always tie them up.



**CAUTION!** If DC inputs are accidentally reversed or inverter is faulty or not working properly, it is NOT allowed to turn off the DC switch. Otherwise, it may cause DC arc and damage the inverter or even lead to a fire disaster. The correct actions are:

- Use a clip-on ammeter to measure the DC string current.
- If it is above 0.5A, please wait for the solar irradiance reduces until the current decreases to below 0.5A.
- Only after the current is below 0.5A, you are allowed to turn off the DC switches and disconnect the PV strings.
- To eliminate the possibility of failure, please disconnect the PV strings after turning off the DC switch to avoid secondary failures due to continuous PV energy on the next day.

Please note that any damages due to wrong installation are not covered in the device warranty.




**ATTENTION!** If any tools or parts are used in the MC4 connector assembly other than those listed in the MC4 connector manual, neither safety nor compliance with the technical data can be guaranteed.

## 5.3 Battery Connection

A quick connector is used for the battery connection. The battery cable outside diameter must be between 5.5 mm - 8.0 mm. Use a flat blade 3 mm screwdriver for this installation.

**Step 1** Take out the two pre-made battery power cables from the package.

5.5 OT Terminal: R60-8, Recommended cable diameter: 8AWG(8.37mm<sup>2</sup>)



**Step 2** The battery cables shall be connected to the respective BAT terminals: BAT+ and BAT- (see Figure 5.5).

**Step 3** Run the cables into the wire box. Strip 13mm off the ends of each cable.

**Step 4** Crimp the R-type connectors onto the cables. Do not over crimp the connectors.

**Step 5** Remove the terminal bolts and then insert them through the connector holes

**Step 6** Put each bolt back into the proper place, be sure to not reverse the polarity.

**Step 7** Tighten the bolts with a torque wrench screwdriver following the torque specs.

**Step 8 (optional)** Additional circuit breaker recommended: circuit breaker with rating 63A.

## 5.4 AC Connection



**DANGER!** Never connect or disconnect the connectors under load.


**NOTICE!** The AC connection to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.

Before installing the AC cables, be sure that the OCPDs (breakers) are turned off. Use a multimeter to verify that the AC voltages are 0Vac before proceeding.

### 5.4.1 AC Grid & Backup port connection

AC Grid Port is to connect to the grid and AC Backup Port is to connect to the critical load circuit.

#### 5.6 AC output terminals



**Table 5.7** AC output terminals

Port	AC Grid	AC Backup / Gen
Terminal	C10-12	C6-12
Torque	4-5 Nm	4-5 Nm
Recommended cross section	8.37-13.3 mm <sup>2</sup>	5.26-13.3 mm <sup>2</sup>

Inside the inverter wire box "x-U", "x-V", "x-W", "x-N" and "x-PE" are printed next to the port for each port "x" can be "GEN", "BK" or "GRID" indicating the connection ports to generator, back-up and grid respectively. The 3 live wires are connected to x-U, x-V and x-W terminals respectively. The ground wire connects to x-PE. The neutral wire connects to the x-N.

**Step 1** Bring the AC cables for the backup loads panel (backup) and the main service panel (grid) into the inverter wire box. The backup loads panel should not be electrically connected to the main service panel

**Step 2** Strip 13mm from the ends of each cable. Crimp the R-type connectors onto the ends

**Step 3** Remove the terminal bolts, insert them into the connectors, then use a torque wrench to tighten the bolts down

**Step 4** Please refer to the terminal labels to connect the AC wires to the correct terminals

**Step 5** The grid inrush current is 8.5A and the duration is less than 5ms

**Step 6** Additional circuit breaker recommended: circuit breaker with rating 63A

The AC cable used must be dimensioned in accordance with any local and national directives on cable dimensions which specify requirements for the minimum conductor cross-section. Cable dimensioning factors are e.g.: nominal AC current, type of cable, type of routing, cable bundling, ambient temperature, and maximum specified line losses.



**WARNING!** It is important that the AC wires are connected to the right terminals as indicated by the "L1", "L2", "L3", "N" and "Ground" symbols on each AC connector. Damage to the inverter by wrong connections are not covered under warranty !.

In some countries a second protective conductor is required. In each case, observe the applicable regulations for the site.



**WARNING!** The AC connection to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.

Always use separate fuses for consumer load. Use dedicated circuit breakers with load switch functionality for load switching.



**DANGER!** No consumer load should be applied between the mains circuit breaker and the inverter.



**DANGER!** The maximum temperature for connecting AC terminals is 105 °C

## 5.5 Smart Meter installation

Autarco's LQH series hybrid inverter must be connected with the supplied Eastron meters to fulfill the control logic of the self-consumption mode, export power control, monitoring, etc.

An Eastron 3ph meter (With CT): SDM630MCT is provided as default in the inverter box.



**CAUTION!** Make sure the AC cable is totally isolated from AC power before connecting the smart meter or CT

The CT provided in the product box is compulsory for hybrid system installation. It can be used to detect the grid current direction and provide the system operating condition to hybrid inverter.

CT Model: 120A/40mA\_0.5%, ESCT-TA16 120A/40mA


CT Cable: Size – 2.3mm<sup>2</sup>, Length - 1m




Please install the CT on the phase lines at the system grid connection point and the arrow on the CT needs to point to the grid direction.

Lead the CT wires through the CT port at the bottom of the inverter and connect the CT wires to the 6 pin communication terminal block.

### 5.17 Eastron Meter



### 5.18 Connection of the Eastron Meter




The Autarco LQH series inverter uses RS485 cable to communicate with the Meter and the CAN-bus to communicate with the battery's Battery Management System (BMS).



**NOTE!** The CAN cable enables the communication between the inverter and the LFP battery, please check for latest model compatibility before installation.

#### 5.19 Communication ports



#### 5.20 Communication ports

Port	Port	Description
COM	USB	Used for Autarco stick connection
ANTENNA	Antenna	Used for antenna connection for built in Bluetooth signal
COM1	4 hole watertight cable gland	Used for RJ45 connection inside wiring box
COM2	4 hole watertight cable gland	Used for RJ45 connection inside wiring box

Wiring steps for COM1-COM2:

**Step 1** Loosen the cable gland and remove the watertight caps inside the cable gland based on the number of the cables and keep the unused holes with watertight cap


**Step 2** Lead the cable into the holes in the cable gland. (COM1-COM2 Hole Diameter: 6mm)

**Step 3** Connect the cable to the corresponding terminals inside the wiring box.

**Step 4** Reassemble the cable gland and ensure there is no bending or stretching of the cables inside the wiring box.





NOTE! The 4- hole fastening rings inside the cable gland are with openings on the side. Please separate the gap with hand and squeeze the cables into the holes from the side openings.



## 5.6.2

## Communication Port Definition

### 5.21 Communication ports



### 5.22 Communication ports


Port	Type	Function
Ethernet	RJ45	Used for Ethernet communication.
PAR-A	RJ45	(Optional) Parallel operation communication port.
PAR-B	RJ45	(Optional) Parallel operation communication port.
BMS	RJ45	Used for CAN communication between inverter and Lithium battery BMS.
Meter	RJ45	(Optional)Used for RS485 communication between inverter and the smart meter.
Analogic	RJ45	Used for output analogic signal.
DRM	RJ45	(Optional) To realize demand response or logic interface function, this function may be required in UK and Australia.
DIP Switch	-	When a single inverter is running, DIP switch 1 and 2 shall be both at the bottom position. When multiple inverters are paralleled, DIP switch: Option 1: Both the first and last inverter (INV1 & INV3) have 1 of the DIP switch enabled (Either Pin1 or Pin2).Option 2: One of the first and the last inverter (INV1 or INV3) has 2 DIP switches enabled (Both Pin1 & Pin2)

### 5.6.3 BMS Port connection

Take out the pre-made CAN cable from the package and connect one end to battery CAN port and then connect another end to the inverter BMS port.

Cable Length: 3 meters.

#### 5.23 Pre-made BMS cable in Inverter package (cable Length: 3 meters)




**NOTE!** Pin definition of the BMS Port is as follows:

EIA/TIA 568B.

CAN-H on Pin 4: Blue

CAN-L on Pin 5: Blue/White



Procedure for connecting the CAN-cable:

1. Take out the CAN cable (terminal marks 'CAN' on one end and 'to Meter' on the other end).
2. Unscrew the swivel nut from CAN port.
3. Insert the RJ45 terminal with CAN label into the CAN port, then fasten the swivel nut.
4. Connect the other end to the battery.




**NOTE!** For CAN cable pin 4 (blue) and pin 5 (white-blue) are used for the communication. Check with the battery supplier which pins they use. This may be different per vendor.

### 5.6.4 Meter Port connection

Take out the pre-made Meter cable from the package and connect RJ45 end to inverter Meter port and then connect another end with loose RS485 A & B pins to the meter RS485 terminal.

Cable Length: 5 meters

#### 5.24 Pre-made BMS cable in Inverter package (cable Length: 5 meters)




**ATTENTION!**

- Make sure the AC cable is totally isolated from AC power before connecting the Smart meter and CT.
- CT orientation must be correct, otherwise the system will not work correctly.



**NOTE!** Pin definition of the Meter Port is as follows:

- EIA/TIA 568B.
- RS485A on Pin 1: Orange/white
- RS485B on Pin 2: Orange



Procedure for connecting the RS485 cable:

1. Take out the RS485 cable (terminal marks 'RS485' on one end and 'to Battery' on the other end).
2. Unscrew the swivel nut from RS485 port.
3. Insert the Two-pin terminal with RS485 label into the RS485 port, then fasten the swivel nut.
4. Connect the other end to the Meter.

## 5.6.5 DRM Port Connection (Optional)

Autarco inverters support remote shutdown function to remotely control the inverter to power on and off through logic signals. The logic interface is required by some local regulations that can be operated by a simple switch or contactor (Not available in South Africa). When the switch is closed the inverter can be operated normally. When the switch is opened, the inverter will reduce its output power to zero within 5 seconds. Pin 5 and Pin 6 of an RJ45 terminal are used for the logic interface connection.


Table 5.3 DRM Port

Signal	Function
Short Pin5 and Pin6	Inverter Generates
Open Pin5 and Pin6	Inverter Shutdown in 5s

Please follow below steps to assemble the RJ45 connector.

1. Insert the network cable into the communication connection terminal of RJ45.
2. Use the network wire stripper to strip the insulation layer of the communication cable. According to the standard line sequence of figure 5.25 connect the wire to the plug of RJ45, and then use a network cable crimping tool to make it tight.
3. Connect RJ45 to DRM (logic interface).

5.25 Strip the insulation later and connect to RJ45 plug



**NOTE!** To use this function, please contact Autarco if this function is supported in your country.




## 5.6.6 RS485 Port Connection (Optional)

If a 3rd party external device or controller needs to communicate with the inverter, the RS485 port can be used. Modbus RTU protocol is supported by Autarco inverters. To acquire latest protocol document, please contact Autarco local service or Autarco sales team.



**NOTE!** Pin definition of the RS485 Port is as follows:

- EIA/TIA 568B.
- RS485A on Pin 4: Blue
- RS485-B on Pin 5: Blue/White




## 5.6.7 Parallel Terminal Connection (Optional)

Up to 6 units of the inverter can be connected in parallel.  
Please connect the paralleled inverters in daisy chain by using P-A and P-B terminals.  
Standard CAT5 with shielding layers internet cable can be used.



**WARNING!** Follow inverter configuration, Section 6.3 before making any inverter parallel connections!


### 5.26 Parallel Terminal Connection




Procedure for connecting inverters in parallel:

1. Connect parallel inverters in daisy chain, using CAT5 shielded cables, on P<sub>A</sub> & P<sub>B</sub> terminals, as indicated in figure 5.26.
2. Only the first and last inverter (Inverter 1 & Inverter 2) must have both their DIP switches enabled (both PIN 1 & PIN 2)

### 5.27 DIP Switches must be turned ON, only for the first and last inverter for parallel functionality



## 5.28 Parallel system wiring




# 5.8 12-pin communication terminal block

The LQH series is equipped with a 12-pin communication port which can be used for communication with a heat pump, generator or ATS.

## 5.8.1 Heat Pump Control Signal Connection


5.8.1 Heat pump connection



## 5.8.2 G-V Terminal Connection

The G-V terminal is a voltage-free dry contact signal for connecting with generator's NO relay to start up the generator when necessary. When generator operation is not needed, Pin3 and Pin4 is in open circuit. When generator operation is needed, Pin3 and Pin4 is in short circuit.


5.8.2 G-V terminal connection





The ATS240V terminal will output 230V AC voltage when inverter is connected to the grid, when the grid is not available, it will output 0V, then the ATS will transfer to generator.

### 5.8.3 ATS connection



## 5.9

## Inverter remote monitoring


The inverter can be monitored via Wi-Fi, LAN or 4G. All Autarco communication devices are optional and can be purchased separately. Dust cover is provided the inverter package in case the port is not used.

For connection instructions, please refer to the respective Autarco Monitoring Device installation manuals.

The USB type COM port at the bottom of the inverter can connect to Autarco's USB data loggers to realize the remote monitoring via MyAutarco. Please see below, list of compatible Autarco data loggers compatible with this device:


- S2.4G-STICK-D.U1
- S2.LAN-STICK-D.U1
- S2.WIFI-STICK-D.U1

### 5.9 USB Type COM Port



**WARNING!** The USB type COM port is only allowed to connect Autarco data loggers. It is forbidden to be used for other purposes.

## 5.27 Inverter wireless communication function



## 6.1 Preparation & Commissioning



**ATTENTION!** Autarco's installer app is mandatory for installing your LQH inverter!  
Before switching on the inverter, please make sure that:

- You have downloaded and installed Autarco's Installer App.
- The device is accessible for safe operation, maintenance, and service.
- Check and confirm that the inverter is properly installed.
- There is sufficient space for ventilation.
- No tools or other materials are left on the inverter or the battery.
- Autarco compatible USB Communication device is inserted in the COM port.
- A reliable WIFI / LAN / 4G connection is available for system configuration.
- Bluetooth Antenna has been connected to the Antenna port of the inverter.
- All accessories, inverter and battery are connected correctly.
- Cables are routed in a safe place and protected against any mechanical damage.
- Warning signs and labels are affixed.

**Table 6.1** Inverter commissioning sequence

### Turn ON inverter

1. Connect AC side and AC- back-up.
2. Select grid standard
3. Configure all parameters
4. Check polarity of the battery and turn on its DC-switch
5. Turn on solar DC side
6. Check that the inverter initialises

Autarco's Installer app is available on both Android and iOS devices. Here are three ways you may download and install the app:

- Visit [www.autarco.com](http://www.autarco.com) to download the latest version of our app.
- You can search “Autarco” in Google Play or Apple App Store to find the latest version of our app.
- You may scan the QR code below to download the Installer App.




## Monitoring Setup

**Step 1** Login to the Autarco Installer app. Available on both iOS & Android devices.

**Step 2** Select the system being installed, and click on “Set up monitoring”, to set up the monitoring for your system and perform initial inverter configuration.



**ATTENTION!** The system must be designed on Helios already, otherwise configuration cannot proceed.



**Step 3** Enter end user details under monitoring setup. Click “Next” when done.

1 of 3

### End user details

End user type  
Individual - male

First name  
John

Last name  
Doe

Email address  
john.doe@email.com

We'll create a new MyAutarco account for the client once the system setup is successful.

Installation date  
2/16/2024

Next

**Step 4** Press the QR Code button and scan the inverter QR code (Sticker on left side) to retrieve its serial number. Autarco app will display the inverter model selected in Helios during project design.

2 of 3

### Set up monitoring

#### Inverter

Inverter model  
S2.LH10000-MII

Inverter serial number  
[QR Code Button]

#### Monitoring device

Device type  
[Dropdown]

Device serial number  
[Dropdown]

Connection  
Not connected

Connect monitoring device

Detected peripherals

Scan the QR code on the device

**Step 5** Select the monitoring stick connected to the inverter and scan its QR code to retrieve the serial number. Monitoring can be setup via 4G / WIFI / LAN. Please follow Autarco's monitoring stick manuals for further instructions.

2 of 3

### Set up monitoring

#### Inverter

Inverter model  
S2.LH10000

Inverter serial number  
103306023B140002

#### Monitoring device

Device type  
[Dropdown]

S2.WIFI-STICK-D

S2.LAN-STICK-D

S2.GPRS-STICK-D

S2.4G-STICK-D

Cancel

Device type  
S2.4G-STICK-D

Device serial number  
[Dropdown]

Connection  
Not connected

Connect monitoring device

Detected peripherals

Enter new serial number  
[Input Field]

Submit

Scan the QR code on the device



**ATTENTION!** To continue inverter configuration, you must -

- Ensure a compatible Autarco monitoring stick is connected to the inverter's COM port.
- Ensure a reliable WIFI / LAN / 4G network is present.


The first three screenshots show the setup for different network options: 4G-stick, Wi-Fi stick, and LAN stick. Each screen includes an image of the stick, instructions on how to connect it to the inverter's COM port, and a 'Next' button. The fourth screenshot shows the 'Set up monitoring' screen, which includes fields for Inverter model (S2.LH10000), Inverter serial number (103306023B140002), Monitoring device type (S2.4G-STICK-D), and Device serial number (3F123B080A6000FE). It also shows a 'Connection' status of 'Not connected' and a 'Connect monitoring device' button.

**Step 6** Once the monitoring device is connected, you may click “Next” and “Save setup”.


The first screenshot shows the 'Summary' screen with the following information: Inverter 1, Connected, Peripherals: Battery. It includes a 'Save setup' button. The second screenshot shows the 'Next' button at the bottom of the 'Set up monitoring' screen, indicating the setup is complete.

The monitoring setup is complete, and your system is online!  
*Follow section 6.3 to configure your inverter for the first time.*


You can view inverter details in the app. Press “Set up inverter” to configure it for the first time.



**Step 1** Configure the Date and Time for your inverter. You may at any point retrieve the inverter's current settings.



**Step 2** Select the necessary grid code standard required for your installation. Selection must be based on local network requirements.



**Step 3** Select the right “Meter type” & “Meter function” for your installation.

Selection must be based on the meter type you are actually connecting to the inverter.

If there is no meter connected at this moment, please select “No meter” to avoid alarms.

We suggest to select “Meter in grid” and install the meter at the system’s grid connection point.

The 'Meter settings' screen (3 of 6) includes a 'Retrieve current settings' button and two dropdown menus. The first dropdown is for 'Meter type' with options: General 1Ph, Acrel 3Ph, General 3Ph, Standard Eastron 1Ph, Standard Eastron 3Ph, No meter mode, and Cancel. The second dropdown is for 'Meter function' with options: Measuring grid, Measuring load, Grid + PV (Two meters), and Cancel. The 'Next' button is highlighted in blue.

**Step 4** Select the “Battery type” that will be connected to the system.

If there is no battery connected at this moment, select “No Battery”, to avoid alarms

The 'Battery settings' screen (4 of 6) includes a 'Retrieve current settings' button and a dropdown menu for 'Battery type' with the instruction 'Select the battery type connected to the inverter'. The 'Next' button is highlighted in blue.

**Step 5** Set inverter storage settings. Set inverter storage mode between “Self consumption” & “Grid trading”. Refer to Section 6.4 for an explanation on all operating modes.

The 'Storage settings' screen (5 of 6) includes a 'Retrieve current settings' button and a dropdown menu for 'Storage mode' with the instruction 'Select the battery priority'. The 'Next' button is highlighted in blue. Below the dropdown are three toggle switches: 'Grid trading schedule' (Toggled ON), 'Allow charge from grid' (Toggled ON), and 'Reserve battery' (Toggled ON). The 'Cancel' button is at the bottom.



**Step 5a** Turn on and use “Grid trading schedule” if manual control of battery charging and discharging is required with respect to time. Set the charge and discharge current (A) for your battery. You may set up to 3 time slots in the grid trading schedule by pressing “Add time slot”.

The screenshot shows the 'Storage settings' screen with the following details:

- Storage mode:** Grid trading (selected)
- Grid trading schedule:** Toggled ON
- Charge current (A):** 10
- Discharge current (A):** 10
- Time slot 1:** A section for configuring the first time slot, with fields for 'Charge' and 'Discharge' start and end times. An 'Add time slot' button is at the bottom.

**Step 5b** “Allow charge from grid” must be turned on (If turned off, the inverter will not be able to charge the battery when it reaches force charge SOC, and battery may be depleted to 0% SOC). You may turn on and set “Reserved SoC (%)”, if your area experiences frequent black-outs.

**Step 5c** If you wish to use the inverter in off-grid mode, please turn on “Off-grid mode”, and set the “Off-grid minimum charge capacity (%)”. Further explanation for this mode follows in *Section 6.4*.

The screenshot shows the 'Storage settings' screen with the following details:

- Storage mode:** Self consumption (selected)
- Grid trading schedule:** Toggled OFF
- Allow charge from grid:** Toggled ON
- Reserve battery:** Toggled ON
- Off-grid mode:** Toggled ON
- Reserved SoC (%):** A field for setting the reserved state of charge.
- Off-grid minimum charge capacity (%):** A field for setting the minimum charge capacity in off-grid mode.

**Step 6** Your inverter setup is complete!

The screenshot shows a confirmation screen with a green checkmark icon and the text:

**Inverter setup complete**  
The setup has been saved to the inverter.

A 'Close' button is at the bottom.

As seen in *Section 6.3*, the inverter can operate in various operational logics, suiting individual needs.



**ATTENTION!** Symbols    depict “Power consumption” priority.

### 6.5.1


## Self-use mode

This mode stores excess PV power into the battery. If the battery is charged, or there is no battery, the excess PV power will be exported back to the grid/utility company. If the system is set to not export any power, then the inverter will curtail the PV power (derate the inverter output power).

*Figure 6.1* depicts the power consumption priority for this mode. The PV power generation is preferentially supplied to the load, and the excess power is used to charged to battery. After the battery is fully charged, the excess power is sent to the grid; the battery is discharged to the load at night.

This mode supports 6 customizable charge/discharge time settings.

6.1 Self-use mode priority



### 6.5.2

## Grid-trading mode

Grid Trading (or Feed-in Priority) Mode ensures that when domestic loads are supplied, the system will export any excess PV power back to the grid. If the export power quota has been met, then the remaining PV power will be stored in the battery.




**ATTENTION!** This mode should not be used if export power is going to be set to zero.

*Figure 6.2* depicts the power consumption priority for this mode. The PV power generation is preferentially supplied to the load, the excess power is first supplied to the grid, and the battery keeps the basic charge of the battery.

This mode supports 6 customizable charge/discharge time settings.

## 6.2 Grid trading mode priority




## 6.5.3 Off-grid mode

Off-grid mode must only be used by systems that are not electrically connected to the grid at all. This mode is almost like Self-Use Mode, but the PV power will be curtailed if the battery is sufficiently charged, and the domestic load demand is lower than the amount of available PV power.

Figure 6.3 depicts the power consumption priority for this mode.

Passive start: When the grid is lost, inverter enters the off-grid mode passively, and the backup port is off-grid output purely.

## 6.3 Off-grid mode priority



## 6.5.4 Reserve or Backup mode

The reserve or backup mode may be opened in the Self-Use or Grid-Trading Mode.

This mode ensures that the battery is not drained past the Reserve SoC mark. The battery will cycle between 100% and the Reserve SOC.

In case grid power is lost, the battery will have the Reserve SOC at the very least to carry the home through unexpected outage.

## 6.5.5 Grid Trading Schedule (Time of Use)

Grid Trading Schedule is used to customize when and by how much the battery may be allowed to charge or discharge. If the grid trading schedule is turned on, the inverter will only follow this schedule to determine when to charge or discharge the battery.

We recommend enabling “Allow charge from grid”.



**NOTE!** Once enabled, the inverter will use grid power to charge the battery only under two circumstances:

1. The battery drains to the Force Charge SOC.
2. Time of Use is enabled and there is not enough PV power available during the charge window to meet the established current rate.

Grid Trading Schedule is for manual control of the battery charging/discharging. If this setting is turned off, charging/discharging is automatically regulated by the inverter.


## 6.5.6 Peak-shaving mode

Peak-shaving mode is used when the consumption is higher than the max allowed grid export. In that case the battery and PV will supply the electricity needed to meet the demand. The maximum useable grid power is the grid export limit which will be never exceeded while this mode is on. Baseline SoC will be used as a benchmark for the battery, to be always charged at this level in order to meet the demand whenever peak shaving will be needed.

How to set the peak-shaving mode?

1. Choose peak-shaving mode in the settings.
2. Define maximum useable grid power.
3. Set a baseline State of Charge (SoC).

### 6.4 Peak-shaving mode



## 6.5.6 Battery settings

The battery section of the app offers numerous options to customize the interaction between the inverter and the battery. Here, we provide explanations for the functions and features available in this section, allowing users to tailor the inverter's behavior to their specific preferences and requirements.

**Battery Mode** Please select the correct model of the battery. If you don't have a battery, choose "No battery" to ensure accurate configuration.

**Max Charging/Discharging Current** Choose the maximum charge/discharge current. This selection allows you to customize the charging and discharging parameters based on your preferences and requirements.

**Over discharge SOC** The Over discharge SOC (State of Charge) is the minimum battery charge level to which the inverter will discharge. It acts as a safeguard to prevent the battery from discharging beyond this specified threshold, ensuring its longevity and health.

**Over discharge Hysteresis SOC** The Over discharge Hysteresis SOC is a hysteresis threshold that prevents the battery from frequently switching between charging and discharging.

**Forcecharge SOC** The Forcecharge SOC for the battery is the minimum state of charge (SOC) at which the inverter initiates charging the battery from the grid. It specifies the threshold below which the inverter actively engages in recharging the battery to maintain optimal performance.

**Peak-shaving setting** If the switch is enable, the power of force charging will be dynamically adjusted.


**Max Grid power when Force charging** During Forcecharge activation, users have the option to set the maximum power utilized by the grid. This feature allows for customization of the power limit, ensuring control over the amount of energy drawn from the grid during the charging process. (Peak-shaving needs to be activated)

**ECO Function** If PV power is lower than 100W and SOC falls below overdischarge SOC, the inverter will turn off the grid relays and IGBT switching. If forcecharge SOC is reached, it will connect back to grid and charge battery back to overdischarge SOC, then turn off again.

**Battery Wakeup Switch** After Battery wake up command, the inverter powers the DC battery port using Battery Wakeup Voltage and low AMP till BMS communication of battery will be restored and within awaken time.

**Auto Bat Awaken** Automatically trigger the battery wake up every time in the morning when inverter starts up.

The output power of the inverter varies with ambient temperature, as shown in the figure below.



## 7

## Maintenance



**CAUTION!** Do not touch the heat sink when the inverter is in operation. Turn OFF the inverter (see section 6.1) and allow for cooling down before cleaning or maintenance.



**CAUTION!** Never use any solvents, abrasives, or corrosive materials to clean the inverter.

The LQH series inverters require general maintenance to be performed once per year. Impurities such as dust and dirt accumulation on the heat sink may negatively affect the inverter's ability to dissipate heat. Any dirt or dust can be removed with a cloth or soft brush.

## 8

## Disposal

To comply with European Directive 2002/96/EC on waste Electrical and Electronic Equipment (WEEE) and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Ignoring this EU Directive may have severe effects on the environment and public health.

Message Name	Information Description	Troubleshooting Suggestion
Off	Control device to shutdown	Turn on the device in the ON/OFF Setting.
LmtByEPM	The device's output is under controlled	<ul style="list-style-type: none"> <li>- Confirm whether the inverter is connected to an external EPM/meter to prevent reverse current.</li> <li>- Confirm whether the inverter is controlled by an external third-party device.</li> <li>- Confirm whether the power setting of the inverter power control is limited.</li> <li>- Verify settings in section 6.6.7 and check your meter readings.</li> </ul>
LmtByDRM	DRM Function ON	No need to deal with it.
LmtByTemp	Over temperature power limited	No need to deal with it, the device is in normal operation.
LmtByFreq	Frequency power limited	
LmtByVg	The device is in the Volt-Watt mode	<ul style="list-style-type: none"> <li>- Due to the requirements of local safety regulations, when the grid voltage is high, the Volt-watt working mode is triggered, which generally does not need to be dealt with.</li> <li>- Inverter factory test errors causing this mode to open, if you need to close, you can close this mode in LCD, set the process: Main menu → Advanced Settings → Password 0010 → STD mode settings → Working Mode → Working mode: NULL → Save and exit.</li> </ul>
LmtByVar	The device is in the Volt-Var mode of operation	<ul style="list-style-type: none"> <li>- Due to the requirements of local safety regulations, when the grid voltage is high, the Volt-watt working mode is triggered, which generally does not need to be dealt with.</li> <li>- Inverter factory test errors causing this mode to open, if you need to close, you can close this mode in LCD, set the process: Main menu → Advanced Settings → Password 0010 → STD mode settings → Working Mode → Working mode: NULL → Save and exit.</li> </ul>
LmtByUnFr	Under frequency limit	No need to deal with it.
Standby	Bypass run	
StandbySynoch	Off grid status to On grid status	
GridToLoad	Grid to load	
Surge Alarm	On-site grid surge	Grid side fault, restart the device. If it is still not eliminated, please contact the manufacturer's customer service.
OV-G-V01	Grid voltage exceeds the upper voltage range	<ul style="list-style-type: none"> <li>- Confirm whether the power grid is abnormal.</li> <li>- Confirm that the AC cable is properly connected.</li> <li>- Restart the system and check if the fault persists.</li> </ul>
UN-G-V01	Grid voltage exceeds the lower voltage range	
OV-G-F01	Grid frequency exceeds the upper frequency range	
UN-G-F01	Grid frequency exceeds the lower frequency range	
G-PHASE	Unbalanced grid voltage	
G-F-GLU	Grid voltage frequency fluctuation	
NO-Grid	No grid	
OV-G-V02	Grid transient overvoltage	
OV-G-V03	Grid transient overvoltage	
IGFOL-F	Grid current tracking failure	
OV-G-V05	Grid voltage RMS instantaneous overvoltage fault	<ul style="list-style-type: none"> <li>- Confirm whether the power grid is abnormal.</li> <li>- Confirm that the AC cable is properly connected.</li> <li>- Restart the system and check if the fault persists.</li> </ul>
OV-G-V04	Grid voltage exceeds the upper voltage range	
UN-G-V02	Grid voltage exceeds the lower voltage range	
OV-G-F02	Grid frequency exceeds the upper frequency range	
UN-G-F02	Grid frequency exceeds the lower frequency range	
NO-Battery	Battery is not connected	<ul style="list-style-type: none"> <li>- Check on information page 1 – Verify the battery voltage is within standards.</li> <li>- Measure battery voltage at plug.</li> </ul>
OV-Vbackup	Inverting overvoltage	<ul style="list-style-type: none"> <li>- Check whether the backup port wiring is normal</li> <li>- Restart the system, confirm that the fault continues.</li> </ul>

Message Name	Information Description	Troubleshooting Suggestion
Over-Load	Load overload fault	Backup load power is too large, or some inductive load startup power is too large, need to remove some backup load, or remove the inductive load on the backup.
BatName-FAIL	Wrong battery brand selection	Confirm whether the battery model selection is consistent with the actual one.
CAN Fail	CAN Fail	Can failure is a failure of communication between inverter and battery. Check cable conditions. Check to ensure you have it plugged in on the CAN port of the battery and inverter. Check that you are using the right cable. Some batteries require a special battery from the battery manufacturer.
OV-Vbatt	Battery undervoltage detected	Verify battery voltage is within standards. Measure battery voltage at inverter connection point. Contact your battery manufacturer for further service.
UN-Vbatt	Battery overvoltage detected	Restart the system and check if the fault persists. If it is still not eliminated, please contact the manufacturer's customer service.
Fan Alarm	Fan alarm	Check if the internal fan is working correctly or jammed.
OV-DC01 (1020 DATA:0001)	DC 1 input overvoltage	<ul style="list-style-type: none"> <li>- Check if the PV voltage is abnormal</li> <li>- Restart the system, confirm that the fault continues</li> </ul>
OV-DC02 (1020 DATA:0002)	DC 2 input overvoltage	
OV-BUS (1021 DATA:0000)	DC bus overvoltage	Restart the system, confirm that the fault continues.
UN-BUS01 (1023 DATA:0001)	DC bus undervoltage	
UNB-BUS (1022 DATA:0000)	DC bus unbalanced voltage	
UN-BUS02 (1023 DATA:0002)	Abnormal detection of DC bus voltage	
DC-INTF. (1027 DATA:0000)	DC hardware overcurrent (1, 2, 3, 4)	Check if the DC wires are connected correctly without loose connection.
OV-G-I (1018 DATA:0000)	A phase RMS value overcurrent	<ul style="list-style-type: none"> <li>- Confirm that the grid is abnormal.</li> <li>- Confirm that the AC cable connection is not abnormal.</li> <li>- Restart the system, confirm that the fault continues.</li> </ul>
OV-DCA-I (1025 DATA:0000)	DC 1 average overcurrent	Restart the system, confirm that the fault continues.
OV-DCB-I (1026 DATA:0000)	DC 2 average overcurrent	
GRID-INTF. (1030 DATA:0000)	AC hardware overcurrent (abc phase)	
Message Name	Information Description	Troubleshooting Suggestion
DCInj-FAULT (1037 DATA:0000)	The current DC component exceeds the limit	<ul style="list-style-type: none"> <li>- Confirm that the grid is abnormal.</li> <li>- Confirm that the AC cable connection is not abnormal.</li> <li>- Restart the system, confirm that the fault continues.</li> </ul>
IGBT-OV-I (1048 DATA:0000)	IGBT overcurrent	Restart the system, confirm that the fault continues.
OV-TEM (1032 DATA:0000)	Module over temperature	<ul style="list-style-type: none"> <li>- Check whether the surrounding environment of the inverter has poor heat dissipation.</li> <li>- Confirm whether the product installation meets the requirements.</li> </ul>
RelayChk-FAIL (1035 DATA:0000)	Relay failure	Restart the system, confirm that the fault continues.
UN-TEM (103A DATA:0000)	Low temperature protection	<ul style="list-style-type: none"> <li>- Check the working environment temperature of the inverter.</li> <li>- Restart the system to confirm if the fault continues.</li> </ul>
PV ISO-PRO01 (1033 DATA:0001)	PV negative ground fault	<ul style="list-style-type: none"> <li>- Check whether the PV strings have insulation problems.</li> <li>- Check whether the PV cable is damaged.</li> </ul>
PV ISO-PRO02 (1033 DATA:0002)	PV positive ground fault	



Message Name	Information Description	Troubleshooting Suggestion
12Power-FAULT (1038 DATA:0000)	12V undervoltage failure	<ul style="list-style-type: none"> <li>- Check current leakage to ground. Verify your grounding.</li> <li>- Verify all wires are in good condition and not leaking current to ground.</li> </ul>
ILeak-PRO01 (1034 DATA:0001)	Leakage current failure 01 (30mA)	
ILeak-PRO02 (1034 DATA:0002)	Leakage current failure 02 (60mA)	
ILeak-PRO03 (1034 DATA:0003)	Leakage current failure 03 (150mA)	
ILeak-PRO04 (1034 DATA:0004)	Leakage current failure 04	
ILeak_Check (1039 DATA:0000)	Leakage current sensor failure	
GRID-INTF02 (1046 DATA:0000)	Power grid disturbance 02	<ul style="list-style-type: none"> <li>- Confirm whether the grid is seriously distorted.</li> <li>- Check whether the AC cable is connected reliably.</li> </ul>
OV-Vbatt-H/ OV-BUS-H (1051 DATA:0000)	Battery overvoltage hardware failure / VBUS	<ul style="list-style-type: none"> <li>- Check if the battery circuit breaker is tripping.</li> <li>- Check if the battery is damaged.</li> </ul>
OV-ILLC (1052 DATA:0000)	LLC hardware overcurrent	<ul style="list-style-type: none"> <li>- Check whether the backup load is overloaded.</li> <li>- Restart the system, confirm that the fault continues.</li> </ul>
INI-FAULT (1031 DATA:0000)	AD zero drift overlink	Restart the system, confirm that the fault continues.
DSP-B-FAULT (1036 DATA:0000)	The master-slave DSP communication is abnormal	
AFCI-Check (1040 DATA:0000)	AFCI self-test failure	
ARC- FAULT (1041 DATA:0000)	AFCI failure	Verify connections are tight within your PV system. Arc fault settings can be changed in advanced settings if further adjustment is necessary.



**NOTE!** If the inverter displays any alarm message as listed above: please turn off the inverter and wait 5 minutes before restarting it. If the fault persists, contact your installer or Autarco.

Before contacting us, please have the following information available:

- Inverter serial number.
- Name of the installer or distributor of the inverter.
- The description of the problem together with necessary information, pictures, attachment.
- Type of battery installed and system configuration.
- Installation date.
- PV array information (no. of panels, capacity, no. of strings, etc.)
- Information on the fault.

Technical Data	S2.LQH12000	S2.LQH15000
	Input DC (PV side)	
Recommended max. PV power	19200W	24000W
Max. input voltage	1000V	
Rated voltage	600V	
Start-up voltage	160V	
MPPT voltage range	200-850V	
Full load MPPT voltage range	200-850V	
Max. input current	20A/20A	
Max. short circuit current	30A/30A	
MPPT number/Max input strings number	4/4	
Max input power per MPPT	12000W	
	Battery	
	LFP	
Battery Type	LFP	
Battery Voltage range	120 - 800Vdc	
Maximum charging Power	12kW	15kW
Maximum Charge/discharge current	50A	
Communication	CAN/RS485	
	Output AC (Grid-side)	
Rated output power	12kW	15kW
Max. apparent output power	12kVA	15kVA
Rated grid voltage	3/N/PE, 380V/400V	
The grid voltage range	320-460V	
Rating grid frequency	50 Hz/60 Hz	
AC grid frequency range	45-55 Hz/ 55-65Hz	
Rating grid output current	18.2A/17.2A	22.8A/21.7A
Max. output current	18.2A/17.2A	9.1A/8.7A
Power factor	> 0.99 ( 0.8 leading to 0.8 lagging)	
THDi	< 3%	
	Input AC (Grid-side)	
Max. input power	18kW	22.5kW
Rated input current	27.3A/26.0A	34.2A/32.5A
Rated input voltage	3/N/PE, 380V/400V	
Rated input frequency	50 Hz/60 Hz	
	Input Generator	
Max. input power	12kW	15kW
Rated input current	18.2A/17.3A	22.8A/21.7A
Rated input frequency	50 Hz/60 Hz	
	Output AC (Back-up)	
Rated output power	12kW	15kW
Peak apparent output power	2 x rated power, 10 seconds	
Back-up switch time	< 10ms	
Rated output voltage	3/N/PE, 380V/400V	
Rated frequency	50 Hz/60 Hz	
Rated output current	18.2A/17.3A	22.8A/21.7A
Max. allowable phase imbalance	40%	
THDv(@linear load)	<2%	
	Efficiency	
Max. efficiency	97.7%	
EU efficiency	97.5%	
BAT charged by PV Max. efficiency	98.5%	
BAT charged/discharged to AC Max. efficiency	97.2%	
MPPT efficiency	99.9%	

Protection	
Anti-islanding protection	Yes
Output over voltage protection	Yes
Insulation resistance monitoring	Yes
Residual current detection	Yes
Output over current protection	Yes
Short circuit protection	Yes
Integrated AFCI (DC arc-fault circuit protection)	Yes
Integrated DC switch	Yes
DC reverse polarity protection	Yes
PV overvoltage protection	Yes
Battery reverse protection	Yes
General data	
Dimensions(W/H/D)	563*546*235mm
Weight	33.4kg
Topology	Transformer less
Self-consumption (Night)	<25 W
Operation temperature range	-25°C+60°C
Relative humidity	0-95%
Ingress protection	IP66
Noise emission	<65 dB(A)
Cooling concept	smart cooling
Max. operation altitude	2000m
Grid connection standard	G98 or G99, VDE-AR-N 4105 / VDE V 0124, EN 50549-1, VDE 0126 / UTE C 15/VFR:2019, RD 1699/RD 244 / UNE 206006 / UNE 206007- 1, CEI 0-21, C10/11, NRS 097-2-1, TOR, EIFS 2018.2, IEC 62116, IEC 61727, IEC 60068, IEC 61683, EN 50530, MEA, PEA
Safety/EMC standard	IEC 62109-1/-2 ,EN 61000-6-1/-3, IEC 61000-2
Features	
PV connection	MC4 connector
Battery connection	OT terminal
AC connection	OT terminal
Display	LED + Bluetooth + APP
Communication	CAN, RS485, Cellular, LAN
Warranty	5 years (extend to 20 years)

Technical Data		S2.LQH20000
		Input DC (PV side)
Recommended max. PV power		32000W
Max. input voltage		1000V
Rated voltage		600V
Start-up voltage		160V
MPPT voltage range		200-850V
Full load MPPT voltage range		200-850V
Max. input current		20A/20A
Max. short circuit current		30A/30A
MPPT number/Max input strings number		4/4
Max input power per MPPT		12000W
		Battery
Battery Type		LFP
Battery Voltage range		120 - 800Vdc
Maximum charging Power		20kW
Maximum Charge/discharge current		50A
Communication		CAN/RS485
		Output AC (Grid-side)
Rated output power		20kW
Max. apparent output power		20kVA
Rated grid voltage		3/N/PE, 380V/400V
The grid voltage range		320-460V
Rating grid frequency		50 Hz/60 Hz
AC grid frequency range		45-55 Hz/ 55-65Hz
Rating grid output current		30.4A/28.9A
Max. output current		30.4A/28.9A
Power factor		> 0.99 ( 0.8 leading to 0.8 lagging)
THDi		< 3%
		Input AC (Grid-side)
Max. input power		30kW
Rated input current		45.6A/43.3A
Rated input voltage		3/N/PE, 380V/400V
Rated input frequency		50 Hz/60 Hz
		Input Generator
Max input power		20kW
Rated input current		30.4A/28.9A
MPPT number/Max input strings number		50 Hz/60 Hz
		Output AC (Back-up)
Rated output power		20kW
Peak apparent output power		40kW, 10s
Back-up switch time		< 10ms
Rated output voltage		3/N/PE, 380V/400V
Rated frequency		50 Hz/60 Hz
Rated output current		30.4A/28.9A
Max allowed phase imbalance		40%
THDv(@linear load)		<2%
		Efficiency
PV Max. efficiency		97.7%
EU efficiency		97.5%
BAT charged by PV Max. efficiency		98.5%
BAT charged/discharged to AC Max. efficiency		97.2%
MPPT efficiency		99.9%

Technical Data		S2.LQH20000
		Protection
Anti-islanding protection		Yes
AFCI		Yes
Insulation Resistor detection		Yes
Residual current monitoring unit		Yes
Output over current protection		Yes
Output short protection		Yes
Output over voltage protection		Yes
DC switch		Yes
DC reverse polarity protection		Yes
PV overvoltage protection		Yes
Battery reverse protection		Yes
		General data
Dimensions(W/H/D)		563*546*235mm
Weight		33.4kg
Topology		Transformer less
Self-consumption (Night)		<25 W
Operation temperature range		-25°C+60°C
Relative humidity		0-95%
Ingress protection		IP66
Noise emission		<65 dB(A)
Cooling concept		Smart cooling
Max. operation altitude		2000m
Grid connection standard		G98 or G99, VDE-AR-N 4105 / VDE V 0124, EN 50549-1, VDE0126 / UTE C 15/VFR:2019, RD 1699/RD 244 / UNE 206006 / UNE 206007-1, CEI 0-21, C10/11, NRS 097-2-1, TOR, EIFS 2018.2, IEC 62116, IEC 61727, IEC 60068, IEC 61683, EN 50530, MEA, PEA
Safety/EMC standard		IEC 62109-1/-2, EN 61000-6-1/-3, , IEC 61000-2
		Features
PV connection		MC4 connector
Battery connection		OT terminal
AC connection		OT terminal
Display		LED + Bluetooth + APP
Communication		CAN, RS485, Cellular, LAN
Warranty		5 years (extend to 20 years)

Scan the QR Code to download Autarco's Installer app!

